



- 1) Front rail support: Insert rods into front of lowBase and tighten lift n' lock blue knobs.
- 2) Rear rail support: Turn lowBase upside-down. Insert rods into back of lowBase and tighten outermost hex screws with provided tool.
- 3) Align camera with lowBase so the front of camera is flush against the front lip. Secure with the appropriate camera screw(s) for your camera.