
PLEASE READ ALL INSTRUCTION PRIOR TO ADDING YOUR NEW FILTER STAGE.

REMOVE (12) SCREWS FROM BACK SIDE OF LENS ADAPTER WTIH .050" ALLEN WRENCH.

THESE WILL BE REUSED LATER.



3

PROJECT: MICRO MATTE BOX

TITLE: STEP 1


IIILE. SILI I

DRAWING NUMBER ADD A STAGE


SCALE 1:1 SIZE B REV. A SHEET 1 OF 8

DO NOT SCALE DRAWING

2




2



2

ROTATE THE NEW STAGE 90 DEGREES TO LINE UP THE NEW STAGE RAILS WITH THE LOWER STAGE RAILS. THEY SHOULD CLICK IN PLACE.



3



PROJECT: MICRO MATTE BOX

TITLE: STEP 6

DRAWING NUMBER

ADD A STAGE

SCALE 1:1 SIZE B REV. A

SHEET 6 OF 8

С

В

4

2

2