



COMPLETE ASSEMBLY

Align backPack with ultraCage as shown, making sure the top side is facing up.
From inside the cage, tighten 4 provided screws from the 'M' Plate into the side rails of the backPack.