



Company: REDROCK MICRO


Pages: 1 of 1

Title: ultraCage | blue Studio SETUP GUIDE



Scene: ultraCage | blue Studio BASIC and DELUXE Bundles

Date: 04.01.12


ultraCage | blue Studio BASIC Bundle Components



ultraCage | blue Studio Additional Options




- A: Insert 14" Rods into top clamps of both front and rear cage.
B: Attach microMount fitted with Cold Shoe to 4" Grip Rod, then to top rail. Attach C300/C500 external monitor to Cold Shoe.



- C: **QUICK RELEASE option:** Insert four 9" Rods into ultraCage as shown. This makes it easy to toggle between handheld and studio modes.
D: **EXTENDED option:** Insert 18" Rods into bottom clamps of ultraCage. For studio mode, this provides maximum stability.

ADDITIONAL OPTIONS



- E: Attach backPack to Rear Chassis.
F: Attach Top Handle. See above note.
G: Screw powerPack into place on cage.
H: Attach microFollowFocus | blue studio to rig.
I: Add a microMattebox to complete your rig.